



SYSTEM AIR CONDITIONER

| INDOOR UNIT | OUTDOOR UNIT |
|------------------------|--------------|
| Basic : EH035EAV | UH035EAV |
| EH052EAV | UH052EAV |
| EH070EAV | UH070EAV |
| Model : EH035EAV1 | UH035EAV1 |
| EH052EAV1 | UH052EAV1 |
| EH070EAV1 | UH070EAV1 |
| Model Code : EH035EAV1 | UH035EAV1 |
| EH052EAV1 | UH052EAV1 |
| EH070EAV1 | UH070EAV1 |

SERVICE *Manual*

AIR CONDITIONER



THE FEATURE OF PRODUCT

- Built-in duct type
- High performance & Energy saving
- Long piping (Length & Height)
- Long ambient operation (In low temp.)
: Up to -10°C(Heating) & Up to -5°C(Cooling)
- Eco-friendly product
(Lead-free, RoHS, WEEE)

Refer to the service manual in the GSPN(see the rear cover) for the more information.

Contents

| | |
|--|------------|
| 1. Precautions | 1-1 |
| 1-1 Installing the air conditioner | 1-1 |
| 1-2 Power supply and circuit breaker | 1-1 |
| 1-3 During operation | 1-1 |
| 1-4 Disposing of the unit | 1-2 |
| 1-5 Others | 1-2 |
| 2. Product Specifications | 2-1 |
| 2-1 The Feature of Product | 2-1 |
| 2-2 Product Specifications | 2-2 |
| 2-3 The Comparative Specifications of Product | 2-4 |
| 2-4 Accessory and Option Specifications | 2-5 |
| 3. Alignment and Adjustments | 3-1 |
| 3-1 Indoor Display Error and Check Method | 3-1 |
| 3-2 Outdoor LED Error Display and Check Method | 3-4 |
| 3-3 Setting Option Setup Method | 3-5 |
| 4. Disassembly and Reassembly | 4-1 |
| 4-1 Indoor Unit | 4-1 |
| 4-2 Outdoor Unit | 4-14 |
| 5. Exploded Views and Parts List | 5-1 |
| 5-1 Indoor Unit | 5-1 |
| 5-2 Outdoor Unit | 5-5 |
| 5-3 Ass'y Control Out | 5-11 |
| 6. Electrical Parts List | 6-1 |
| 7. Wiring Diagram | 7-1 |
| 7-1 Indoor Unit | 7-1 |
| 7-2 Outdoor Unit | 7-2 |
| 8. Schematic Diagram | 8-1 |
| 8-1 Indoor Unit | 8-1 |
| 8-2 Outdoor Unit | 8-2 |
| 9. Circuit Descriptions | 9-1 |
| 9-1 PCB Circuit Descriptions | 9-1 |
| 9-2 Refrigerating Cycle Diagram | 9-5 |

Contents

| | |
|---|-------------|
| 10. PCB Diagram | 10-1 |
| 10-1 Indoor PCB | 10-1 |
| 10-2 Outdoor PCB | 10-2 |
| 11. Operating Instructions | 11-1 |
| 11-1 Name of Each Part | 11-1 |
| 11-2 Main Function | 11-3 |
| 11-3 Wireless Remote Control-Buttons and Display | 11-9 |
| 11-4 Wired Remote Controller-Buttons and Display | 11-10 |
| 12. Troubleshooting | 12-1 |
| 12-1 Items to be checked first | 12-1 |
| 12-2 Fault Diagnosis by Symptom | 12-2 |
| 12-3 PCB Inspection Method | 12-19 |
| 12-4 Main Part Inspection Method | 12-21 |
| 13. Block Diagram | 13-1 |
| 13-1 Indoor Unit | 13-1 |
| 13-2 Outdoor Unit | 13-2 |
| 14. Reference Sheet | 14-1 |
| 14-1 Index for Model Name | 14-1 |
| 14-2 Low Refrigerant Pressure Distribution | 14-2 |
| 14-3 Pressure & Capacity mark | 14-3 |
| 14-4 Q & A for Non-trouble | 14-4 |
| 14-5 Cleaning/Filter Change | 14-7 |
| 14-6 Installation | 14-8 |
| 14-7 Installation Diagram of Indoor Unit and Outdoor Unit | 14-9 |